

How to Connect to LAN

Step 1 Click the icon as figure 1.0



Figure 1.0

Step 2, After step 1, it will pop up an operation windows as figure 2.0, please fill in this blank with 'cmd', then click icon 'OK'.



Figure 2.0

Step 3, After step 2, you will enter operation windows as figure 3.0.

Please input message like following format.

net use remoteSupoin \\Supoin-PC\PDA

The 'remoteSupoin' is the name of mapped folder in PDA, you can name it with whatever you wanted.

The 'Supoin-PC' is the name of your PC (such as database server)

The 'PDA' is the name of folder shared by PC in the LAN.

Then you need input user name and password to connect to LAN.




Figure 3.0

The End

www.supoin.net

Fax : 0755-82281509

Tel : 0755-82178516

E-mail : supoin@supoin.com