

Remote Desktop Connection

Step 1, Please click icon 'Windows', then click icon 'Programs' as the figure 1.0.



Figure 1.0

Step 2, Click icon 'Remote Desktop Connection' as figure 2.0.




Figure 2.0

Step 3, it will pop up an operation windows, please fill in this blank with the name or IP address of your PC, then click icon 'Connect'.

As the figure 3.0.



Figure 3.0

Step 4, Please input User's name and relevant password you will use to log in your PC, then click icon 'OK'. As the figure 4.0.



Figure 4.0

The End

www.supoin.net

Fax : 0755-82281509

Tel : 0755-82178516

E-mail : supoin@supoin.com